

**DANCOVER<sup>®</sup>**



PARTY TENT SEMI PRO

6m series

# DANCOVER<sup>®</sup>

.com

## Safety Advice

### Attention

In some countries approval is needed to set up a marquee/tent larger than 75 m<sup>2</sup>. It is your responsibility to comply with local rules and regulations and to ensure that the marquee/tent is assembled correctly.

In case of bad weather conditions, it is your responsibility to ensure the marquee/tent is safely secured and that the marquee/tent does not cause damage to others.

Do not use open fire, welding equipment or other sources which can ignite, inside or close to the tent.

The marquee/tent must be safely secured. We recommend you secure your marquee/tent with straps and pegs as soon as it is assembled.

Make sure to check if the marquee/tent is covered by your home contents insurance.

Marquees/tents must be evacuated under extreme weather conditions.

In the event of snow always remove snow from the roof of the marquee/tent regularly to prevent snow from building on the roof as heavy snow can cause the marquee/tent to collapse.

In the event of rain there is a risk of rain puddles building up on top of the roof of the marquee/tent. Heavy rain puddles can cause the roof to collapse. It is your responsibility to ensure rain puddles do not build up. As a precaution, make sure the roof of the marquee/tent is stretched out properly and adequately over the side frames of the marquee/tent and remove rain water regularly.

Do not unpack or repack your marquee/tent in freezing temperatures. In case of temperatures below zero always unpack and repack your marquee/tent indoors to avoid the risk of cracking parts.

The marquee/tent must be totally dry before you repack and store it to avoid mildew.










Note: Marquees are intended for events and other arrangements and are as such only meant for short term temporary assembly and the following disassembly. Dancover warranty applies only to the normal use of the Product, normal wear and tear excepted, in accordance with written use instructions or manual. The warranty does not apply to damage caused by accident, abuse, misuse, or modification of the Product.

### Warranty Information







Please visit [dancovershop.com](http://dancovershop.com) for information on warranty.

*Please always check our website for the latest safety advice and manual.*







## 6m -2.3 PARTY TENT SEMI PRO

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
Pipe 50-50		1	16	20	24	28	32
Pipe 38-38		2	23	30	37	44	51
Pipe 38-38 with hole		3-1	2	2	2	2	2
		3-2	2	2	2	2	2
Pipe roof brace 6-series horizontal		4	8	10	12	14	16
Pipe roof brace 6-series horizontal		5	4	5	6	7	8
Pipe 25-25 diagonal pipe		6	4	4	4	4	4
Pipe 50-50 with holes		7	4	6	8	10	12
Pipe 50-50 with holes and a hole		8	4	4	4	4	4
connector Three way 110 °54-42		10	4	4	4	4	4







## 6m -2.3 PARTY TENT SEMI PRO

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
connector Three way 140 °54-42		11	2	2	2	2	2
connector four way 140 °54-42		12	2	3	4	5	6
connector four way 110 °54-42		13	4	6	8	10	12
Cross piece 54-42		14	4	6	8	10	12
T-piece 54-42		15	4	4	4	4	4
Connector three way –foot for the corners 54-42		16	2	2	2	2	2







## 6m -2.3 PARTY TENT SEMI PRO

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
Connector three way –foot for the corners 54-42		17	2	2	2	2	2
Connector three way –foot for the sidewalls 54-42		18	4	6	8	10	12
Connector three way –foot for the endwalls 54-42		19	4	4	4	4	4
Groundpegs		20	4	6	8	10	10
Screw hook		21	4	4	4	4	4
Groundpeg 6x180mm		22	8	10	12	14	16



## 6m -2.3 PARTY TENT SEMI PRO

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
Groundpeg 4x180mm		23	36	42	48	54	60
Screw M8X50mm		24	58	72	86	100	114
Screw M8X60mm		25	52	64	76	88	100
Locknuts M8		26	110	136	162	188	214
Wing nut M6		29	16	20	24	28	32
Screw M6X25mm		30	16	20	24	28	32

## 6m -2.3 PARTY TENT SEMI PRO

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
spanner		31	2	2	2	2	2
Long bungeeball		33	112	132	152	172	192
Short bungeeball		34	26	26	26	26	26
rope		35	4	4	4	4	4
roof		37	1	1	1	1	1
sidewall		38	6	8	10	12	14

## 6m -2.3 PARTY TENT SEMI PRO


Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
endwall with large door		39	1	1	1	1	1
endwall with small door		40	1	1	1	1	1



## 6m -2.3 PARTY TENT SEMI PRO


I

Select a flat surface for the tent. Unpack the boxes and check if all listed parts are included. Assemble the roof frame by mounting parts 10-15 on the pipes (Parts 1,2, and 3) Use the screws to firmly attach the parts



II

Attach the reinforcement braces (part 4 and 5) using screws (30) and wing nuts (29)






## 6m -2.3 PARTY TENT SEMI PRO

V

Extend the sidewalls and the endwalls and attach the sidewalls to the frame using the bungees. Attach the endwall directly to the roof using the short bungees. Use the short ground pegs to fasten the end walls to the ground. The guy rope runs from every corner of the tent and is braced to the ground using the screw hooks. The professional ground pegs provide the tent with additional tension and stability.



### **Warning**

1. In order to avoid being rusted by air, oil is covered on the surface of the pipes, before set up the tent, please remove the oil carefully to keep the cover clean.
  2. Take note that the tent needs to be handled carefully to avoid damage.
  3. Do not force the frame as they may be damaged in the process.
  4. Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.
- Please select a suitable site for the tent to avoid the damage to underground sprinkler systems, water, gas or electrical lines.

## Contact information

### Head office:

Dancover A/S  
Nordre Strandvej 119 G  
3150 Hellebæk  
Denmark

For more information  
please visit:  
[www.dancovershop.com](http://www.dancovershop.com)

## National contacts

Denmark: 70 26 76 20  
[denmark@dancover.com](mailto:denmark@dancover.com)

UK: 020 8099 7570  
[uk@dancover.com](mailto:uk@dancover.com)

Germany: 041 0266 7040  
[germany@dancover.com](mailto:germany@dancover.com)

France: 0975 181 800  
[france@dancover.com](mailto:france@dancover.com)

Sweden: 040 233 262  
[sverige@dancover.com](mailto:sverige@dancover.com)

Finland: 0 931 581 720  
[suomi@dancover.com](mailto:suomi@dancover.com)

Poland: 22 300 8602  
[polska@dancover.com](mailto:polska@dancover.com)

Luxembourg: +49 041 0266 7040  
[luxembourg@dancover.com](mailto:luxembourg@dancover.com)

Portugal: 308 800 899  
[portugal@dancover.com](mailto:portugal@dancover.com)

Spain: 911 436 828  
[espana@dancover.com](mailto:espana@dancover.com)

Italy: 02 479 21 198  
[italia@dancover.com](mailto:italia@dancover.com)

Switzerland: 0840 000125  
[schweiz@dancover.com](mailto:schweiz@dancover.com)

Austria: 0662 626935  
[austria@dancover.com](mailto:austria@dancover.com)

Norway: 231 00 690  
[norge@dancover.com](mailto:norge@dancover.com)

Nederland: 0 858 880 524  
[nederland@dancover.com](mailto:nederland@dancover.com)

Ireland: 0 151 33 003  
[ireland@dancover.com](mailto:ireland@dancover.com)

Belgium: 0 28 08 08 09  
[belgique@dancover.com](mailto:belgique@dancover.com)